

COOKPOT™

COOKPOT IH Hot Carbon Plate Set INSTRUCTIONS

IH Hot Carbon 18 Plate Set, IH Hot Carbon 15 Plate Set, IH Hot Carbon 18, IH Hot Carbon 15,
Hot Carbon 18 Plate, Hot Carbon 15 Plate,


Thank you for your purchase. Please be sure to read the instructions before using and follow the safety guidelines. Improper use could lead to accidents. Please read, then keep the instructions for reference.

1. Before use

- Please check to see if there are no cracks or broken parts on the product before using.
- Though we take great care to ensure the quality of our products, if there should be any defects, please notify the store you bought it from or the dealer.

2. About usage

- This product is a special plate for use only with IH cooking heaters (up to 100V-240V/2.5KW) for COOKPOT. Please note that it cannot be used with pans other than COOKPOT or other heating equipment such as gas stoves, etc.
- With some types of IH cooking heaters, this product cannot be used to heat or to heat at highest output.
- When using IH Hot Carbon Plate Set, use IH Hot Carbon that fits the diameter of the pan's bottom. When diameters do not match, IH cooking heater might not work for heating/cooking.
- IH Hot Carbon is a carbon heating element used with IH cooking heaters. Do not place food directly on the carbon.
- The special Hot Carbon Plate is a plate to protect the IH Hot Carbon and IH cooking heater. Do not place food directly on the plate to cook or use for any other purpose than stated.
- If there are cracks in IH Hot Carbon and IH plate, buy and renew the necessary part(s), since they could lead to further damage.
- Be sure to place IH Hot Carbon in the attached special ceramic Hot Carbon Plate as shown in the picture below, and place the bottom surface of the pan in the center of the IH Hot Carbon.



3. Usage Notes

- IH Hot Carbon, made of carbon, is thin and fragile. Please handle with care. Do not drop or apply force. It could be a cause for damage.
- When/right after heating, do NOT touch the IH Hot Carbon and the bottom of the special Hot Carbon Plate, as they become extremely hot. They could cause burns. Cool thoroughly and use pan holders/oven mittens when handling.
- When food/ingredients spill over, do not attempt to scrape off the food. Immediately turn off the IH cooking heater. Remove pan to a pan stand, take the special Hot Carbon Plate, as it is with the IH Hot Carbon on it, to a sink filled with water, and wash with water. When only water boils over, it is not a problem, as the water will evaporate.
- Placing the IH Hot Carbon directly on the IH cooking heater is strictly prohibited. It could break or cause damage to the IH cooking heater.
- The top plate of IH cooking heater is very hot after use. Be very careful not to burn yourself.
- Do not use the automatic cooking button on the IH cooking heater. Heat/cook using manual control.
- Do not place special Hot Carbon Plate over direct heat, as it is not super-heat-resistant.

4. Care and Cleaning

- Do not leave in water for a long time after use. Wash promptly and thoroughly after use. If necessary, use a soft sponge and kitchen detergent with warm water to gently wash off any residue. Do not use cleansers or metal-scrubbing pads to clean the bottom surface, as they could cause cracks and damage. Be sure it is completely dry before storing. If not completely dry, it could become a cause for mold and smell.
- When using IH cooking heaters, make sure to thoroughly wipe dry the bottom of the pan. Please make sure that there are no chips of cut vegetables or any other objects between the IH Hot Carbon and bottom of the pan when heating, as they could cause damage to IH cooking heater and/or IH Hot Carbon. If the contents of the pan boil over, use kitchen detergent and sponge to clean up. Always keep bottom of the pan and IH Hot Carbon clean.
- Use of dishwasher may cause damage. Hand wash separately is recommended.

Slight differences in size, weight, color, etc. may occur due to calcinations.
To improve product quality, specifications may be altered without notice.